

# Vejledning - Fyrfadslys med fjernbetjening

Sådan bruger du fyrfadslys med fjernbetjening:

- Fjern den plastic snip i bunden af lyset
- Tænd på on/off knap i bunden
- Lyset skal være tændt før fjernbetjening kan bruges 1. gang
- Brug evt. den sorte fjernbetjening hvis du har købt den

Mangler du batterier eller fjernbetjening?

Så kan du finde dem lige [her](#)

*Kære dig,*

*Tusind tak for dit miljøvenlige køb hos Lyshygge. Skulle du have nogle spørgsmål til produktet, er du mere end velkommen til at kontakte os. Hav en dejlig dag,*

*De hyggeligste hilsner*

*Kim & Rikke fra Lyshygge*

[www.lyshygge.dk](http://www.lyshygge.dk)

@lyshygge.dk

# Guide - Tealight with remote

How to use tealight with remote:

- Remove the plastic at the bottom of the candle
- Use the on/off button at the bottom of the candle
- Use the remote control (if you purchased one) to control your candle

Do you need batteries or a remote?

Just click on [lednordic.no](http://lednordic.no) or [led-nordic.se](http://led-nordic.se)

*Dear you,*

*Thank you for shopping at LED Nordic. In case you have any questions about your products, you are more than welcome to contact us.*

*Have a great day,*

*Best regards,*

*Kim & Rikke from LED Nordic*

[www.led-nordic.se](http://www.led-nordic.se), [www.lednordic.no](http://www.lednordic.no)

[@lyshygge.dk](https://www.instagram.com/lyshygge.dk)