

Vejledning - Rika kronelys

Sådan bruger du Rika kronelys:

- Fjern forsigtigt dækslet i bunden af lyset ved at dreje på bunden
- Indsæt batterier og sæt forsigtigt dækslet på igen
- Tryk i bunden for at tænde lyset
- Der er indbygget 6 timers timer

Mangler du batterier?

Så kan du finde dem lige [her](#)

Kære dig,

Tusind tak for dit miljøvenlige køb hos Lyshygge. Skulle du have nogle spørgsmål til produktet, er du mere end velkommen til at kontakte os. Hav en dejlig dag,

De hyggeligste hilsner

Kim & Rikke fra Lyshygge

www.lyshygge.dk

@lyshygge.dk

Guide - Rika taper

How to use Rika taper:

- Remove the base of the candle carefully by turning the base
- Insert the batteries and replace the base carefully
- It has a 6-hour timer

Do you need batteries?

Just click on lednordic.no or led-nordic.se

Dear you,

Thank you for shopping at LED Nordic. In case you have any questions about your products, you are more than welcome to contact us.

Have a great day,

Best regards,

Kim & Rikke from LED Nordic

www.led-nordic.se, www.lednordic.no

[@lyshygge.dk](https://www.instagram.com/lyshygge.dk)